

Getting Acquainted

Congratulations upon your selection of this CASIO watch. To get the most out of your purchase, be sure to carefully read this manual and keep it on hand for later reference when necessary.

Expose the watch to bright light to charge its battery before using it.

You can use this watch even as its battery is being charged by exposure to bright light.

- Be sure to read "Battery" of this manual for important information you need to know when exposing the watch to bright light.

If the display of the watch is blank...




If the Power Saving on (S) indicator flashes on the display, it means that the display is blank because the watch's Power Saving function has turned off the display to conserve power. Power Saving automatically turns off the display and puts the watch into a sleep state whenever your watch is left for a certain period where it is dark.

- The initial factory default setting is Power Saving on.
- The watch recovers from the sleep state if you move it to a well-lit area *, if you press any button, or if you angle the watch towards your face for reading.
- * It can take up to five seconds for the display to turn on.
- See "Power Saving function" for more information.


General Guide

- Press (C) to change from mode to mode.
- In any mode (except when a setting screen is on the display), press (B) to illuminate the display.



Timekeeping


Use the Timekeeping Mode to set the time and date.



Note
This watch is capable of displaying text for the day of the week in any one of 16 different languages (English, Portuguese, Spanish, French, Dutch, Danish, German, Italian, Czech, Swedish, Polish, Greek, Romanian, Turkish, Russian, and Japanese).

To set the time and date

1. In the Timekeeping Mode, hold down (A) until the seconds start to flash, which indicates the setting screen.
2. Use (C) to move the flashing in the sequence shown below to select other settings.



- The currently selected language indicator flashes on the display while the Language (setting) is selected in the above sequence.
3. When the setting you want to change is flashing, use (B) and (D) to change it as described below.

To change this setting	Perform this button operation
Seconds	Press (D) to reset to 00.
DST on/off	Press (D) to toggle between Daylight Saving Time (ON displayed) and standard time (OFF displayed).
Hour, Minutes, Year, Month, Day	Use (D) (+) and (B) (-) to change the setting.
Language	Use (B) and (D) to change the language setting.

- While the language indicator is flashing on the display, use (B) and (D) to cycle through the language indicators as shown below, until the one for the language you want to select is displayed.

Indicator	Language	Indicator	Language	Indicator	Language
ENG	English	DEU	German	ROM	Romanian
POR	Portuguese	ITA	Italian	TUR	Turkish
ESP	Spanish	CES	Czech	PYC	Russian
FRA	French	SVE	Swedish	JPN	Japanese
NED	Dutch	POL	Polish		
DAN	Danish	GRE	Greek		

4. Press (A) to exit the setting screen.
- The day of the week is automatically displayed in accordance with the date (year, month, and day) settings.
- See the "Day of the Week List" for information on abbreviations used.

About This Manual




- Button operations are indicated using the letters shown in the illustration.
- Each section of this manual provides you with the information you need to perform operations in each mode. Further details and technical information can be found in the "Reference" section.


World Time Mode



Data Bank Mode



Day Counter Mode



Alarm Mode



- In addition to the day of the week display, the language setting also affects the type of characters you can input for the name in the Data Bank Mode and the text in the Day Counter Mode.

- Holding down (A) in the Timekeeping Mode displays the indicator for the currently selected language. Keeping (A) depressed for about two seconds changes to the Timekeeping Mode setting screen (indicated by the seconds flashing). If you accidentally display the setting screen, press (A) again to exit.

To toggle between 12-hour and 24-hour timekeeping

1. In the Timekeeping Mode, press (D) to toggle between 12-hour timekeeping (indicated by A or P on the display), or 24-hour timekeeping.
- With the 12-hour format, the P (PM) indicator appears on the display for times in the range of noon to 11:59 p.m. and the A (AM) indicator appears for times in the range of midnight to 11:59 a.m.
- With the 24-hour format, times are displayed in the range of 0:00 to 23:59, without any indicator.
- The 12-hour/24-hour timekeeping format you select in the Timekeeping Mode is applied in all modes.


Daylight Saving Time (DST)

Daylight Saving Time (summer time) advances the time setting by one hour from Standard Time. Remember that not all countries or even local areas use Daylight Saving Time.

To toggle the Timekeeping Mode time between DST and Standard Time

1. In the Timekeeping Mode, hold down (A) until the seconds start to flash, which indicates the setting screen.
 2. Press (C) to move the flashing to the DST on/off setting.
 3. Press (D) to toggle between Daylight Saving Time (ON displayed) and standard time (OFF displayed).
 4. Press (A) to exit the setting screen.
- The DST indicator appears on the display to indicate that Daylight Saving Time is turned on in the Timekeeping, Alarm, and Day Counter Mode.

World Time



The World Time shows the current time in 28 cities (29 time zones) around the world.

- The time settings of the Timekeeping Mode and the World Time Mode are independent from each other, so you must make separate settings for any city in the World Time Mode, the settings of all other cities are changed accordingly.
- Whenever you change the time setting for any city in the World Time Mode, the settings of all other cities are changed accordingly.
- The UTC differential value indicates the number of hours difference in time between the currently selected time zone and UTC.
- All of the operations in this section are performed in the World Time Mode, which you enter by pressing (C).

To set the current time in the World Time Mode

1. In the World Time Mode, use (D) to select the city code whose time you want to set.
2. After you select a city code, hold down (A) until the DST on/off setting of the World time starts to flash, which indicates the setting screen.
3. Use (C) to move the flashing in the sequence shown below to select other settings.



4. When the setting you want to change is flashing, use (B) and (D) to change it as described below.

To change this setting	Perform this button operation
DST on/off	Press (D) to toggle between Daylight Saving Time (DL displayed) and standard time (ST displayed). • The above operation toggles all World Time city codes between Daylight Saving Time and Standard Time.
Hour, Minutes	Use (D) (+) and (B) (-) to change the setting.

- While the settings are flashing on the display, pressing (B) and (D) at the same time changes the DST on/off, hour, and minutes settings so they match the Timekeeping Mode time.
 - When setting the world time using the 12-hour format, take care to set the time correctly as a.m. (A indicator) or p.m. (P indicator).
5. Press (A) to exit the setting screen.
 - The DST indicator appears on the display to indicate that Daylight Saving Time is turned on in the World Time Mode.
 - Note that you cannot make settings for individual city codes. Daylight Saving Time (summer time) advances the time setting by one hour from Standard Time. Remember that not all countries or even local areas use Daylight Saving Time.

To view the time in another city code


- In the World Time Mode, press (D) to scroll city codes (time zones).
- For full information on city codes, see the "City Code Table".

Data Bank

Remaining memory



Name




Telephone number


The Data Bank Mode lets you store up to 30 records, each containing name and telephone number data. Records are automatically sorted based on the characters of the name. You can recall records by scrolling through them on the display.

- The characters you can input for the name depend on the language you select in the Timekeeping Mode. See "To set the time and date" for more information. Changing the language setting does not affect names that are already stored.
- See "Sort Table" for details on how the watch sorts records.
- All of the operations in this section are performed in the Data Bank Mode, which you enter by pressing (C).

To create a new Data Bank record



New Data Screen



- The above character sequence is for English input. See "Character List" for the character sequences of other languages.
4. When the character you want is at the cursor position, press (C) to move the cursor to the right.
 5. Repeat steps 3 and 4 until the name is complete.
 - You can input up to eight characters for the name.
 6. After you input the name, press (C) as many times as necessary to move the cursor to the number area.
 - When the cursor is located at the eighth space of the name area, moving the cursor to the right causes it to jump to the first digit of the number. When the cursor is at the 16th digit of the number, moving it to the right (by pressing (C)) causes it to jump to the first character in the name.
 7. In the number area, use (B) and (D) to cycle through numbers and symbols (hyphen, brackets, space) at the cursor position. The characters cycle in the sequence shown below.
- Press (D):
-
- Press (B):
-
8. When the character you want is at the cursor position, press (C) to move the cursor to the right.
 9. Repeat steps 7 and 8 until you complete number input.
 - You can input up to 16 digits for the number.
 - The number initially contains all hyphens. You can leave the hyphens as they are or replace them with numbers or other symbols (brackets, space).

10. Press (A) to store your data and return to the Data Bank record screen (without the cursor).
- When you press (A) to store data, the name and number you input flash for about one second as Data Bank records are sorted. After the sort operation is complete, the Data Bank record screen appears.
 - The name can show only three characters at a time, so longer text scrolls continuously from right to left. The last character is indicated by the symbol # after it.

To recall Data Bank records

In the Data Bank Mode, use (D) to scroll through Data Bank records on the display.


To edit a Data Bank record

1. In the Data Bank Mode, use (D) to scroll through the records and display the one you want to edit.
2. Hold down (A) until the flashing cursor appears on the display.
3. Use (C) to move the flashing to the character you want to change.
4. Use (D) (forward) and (B) (back) to change the character.
5. After making the changes that you want, press (A) to store them and return to the Data Bank record screen.

To delete a Data Bank record

1. In the Data Bank Mode, use (D) to scroll through the records and display the one you want to delete.
2. Hold down (A) until the flashing cursor appears on the display.
3. Press (B) and (D) at the same time to delete the record.
- The message CLR appears to indicate that the record is being deleted. After the record is deleted, the cursor appears on the display, ready for input.
4. Input data or press (A) to return to the Data Bank record screen.

Alarms



You can set up to five independent multi-function alarms with hour, minutes, month, and day. When an alarm is turned on, the alarm tone sounds when the alarm time is reached. One of the alarms can be configured as a snooze alarm or a one-time alarm, while the other four are one-time alarms.

- You can also turn on an Hourly Time Signal that causes the watch to beep twice every hour on the hour.
- There are five alarms numbered 1 through 5. You can configure Alarm 1 as a snooze alarm or a one-time alarm. Alarms 2 through 5 can be used as one-time alarms only.
 - Alarm settings (and Hourly Time Signal settings) are available in the Alarm Mode, which you enter by pressing (C).


Alarm Types

The alarm type is determined by the settings you make, as described below.

- **Daily alarm**
Set the hour and minutes for the alarm time. This type of setting causes the alarm to sound everyday at the time you set.
- **Date alarm**
Set the month, day, hour and minutes for the alarm time. This type of setting causes the alarm to sound at the specific time, on the specific date you set.
- **1-Month alarm**
Set the month, hour and minutes for the alarm time. This type of setting causes the alarm to sound everyday at the time you set, only during the month you set.
- **Monthly alarm**
Set the day, hour and minutes for the alarm time. This type of setting causes the alarm to sound every month at the time you set, on the day you set.


To set an alarm time

1. In the Alarm Mode, use (D) to scroll through the alarm screens until the one whose time you want to set is displayed.



- Each of the five alarm screens has an alarm number. The Hourly Time Signal screen does not have an alarm number.
2. After you select an alarm, hold down (A) until the hour setting of the alarm time starts to flash, which indicates the setting screen.
 - This operation automatically turns on the alarm.

3. Use (C) to move the flashing in the sequence shown below to select other settings.



4. While a setting is flashing, use (D) (+) and (B) (-) to change it.
 - To set an alarm that does not include a month (Daily alarm, Monthly alarm), set - for the month. Use (D) and (B) until the - mark appears (between 12 and 1) while month setting is flashing.
 - To set an alarm that does not include a day (Daily alarm, 1-Month alarm), set -- for the day. Use (D) and (B) until the -- mark appears (between the end of the month and 1) while the day setting is flashing.
 - When setting the alarm time using the 12-hour format, take care to set the time correctly as a.m. (A indicator) or p.m. (P indicator).
5. Press (A) to exit the setting screen.

Alarm Operation

The alarm tone sounds at the preset time for 10 seconds, regardless of the mode the watch is in. In the case of the snooze alarm, the alarm operation is performed a total of seven times, every five minutes, until you turn the alarm off or change it to a one-time alarm.

- Pressing any button stops the alarm tone operation.
- Performing any one of the following operations during a 5-minute interval between snooze alarms cancels the current snooze alarm operation.

Displaying the Timekeeping Mode setting screen
Displaying the alarm 1 setting screen

To test the alarm

- In the Alarm Mode, hold down (D) to sound the alarm.


To turn Alarms 2 through 5 and the Hourly Time Signal on and off

1. In the Alarm Mode, use (D) to select a one-time alarm (alarm number 2 through 5) or the Hourly Time Signal.
2. Press (A) to toggle it on and off.
- The on/off status of Alarms 2 through 5 and the Hourly Time Signal is shown by indicators along the bottom of the displays.
- The alarm on indicators and Hourly Time Signal on indicator are displayed in all modes.
- While an alarm is sounding, the applicable alarm on indicator flashes on the display.

To select the operation of Alarm 1

1. In the Alarm Mode, use (D) to select Alarm 1.
2. Press (A) to cycle through the available settings in the sequence shown below.

Snooze on indicator and Alarm 1 on indicator



- The snooze on indicator and Alarm 1 on indicator are displayed in all modes.
- The snooze on indicator flashes during the 5-minute intervals between alarms.
- The alarm indicator (Alarm 1 on and/or snooze on) flashes while the alarm is sounding.

Day Counter


The Day Counter lets you count the number of days from the Timekeeping Mode's current date to a specific target date.

- There are five Day Counter records, each of which can be set with its own text and target date (year, month, day).
- When the target date falls before the current date (as kept in the Timekeeping Mode), the number of days is displayed as a negative value.
- Whenever the date specified by any one of the Day Counters matches the date of the Timekeeping Mode (regardless of the Day Counter's year setting), the DAYS indicator flashes on the Timekeeping Mode and Day Counter Mode.


- The initial default target date when you purchase the watch, after you have its battery replaced, or when battery power drops to Level 5 is January 1, 2001.
- The characters you can input for the text depend on the language you select in the Timekeeping Mode. See "To set the time and date" for more information. Changing the language setting does not affect texts that are already stored.
- All of the operations in this section are performed in the Day Counter Mode, which you enter by pressing (C).

To create a new Day Counter record

1. In the Day Counter Mode, use (D) to scroll through the Day Counter records until the one you want is on the display.
2. Hold down (A) until the flashing cursor appears in the text area of the display, which indicates the setting screen.
3. Press (C) to move the flashing in the sequence shown below.



4. While the cursor is in the text area, use (B) and (D) to cycle through characters at the cursor position. The characters cycle in the sequence shown below.



- The above character sequence is for English input. See "Character List" for the character sequences of other languages.
5. When the character you want is at the cursor position, press (C) to move the cursor to the right.
 6. Repeat steps 4 and 5 until the name is complete.
 - You can input up to eight characters for the text.
 7. After you input the text, press (C) as many times as necessary to move the cursor to the target date.
 - When the cursor is located at the eighth space of the text area, moving the cursor to the right causes it to jump to the year setting. When the cursor is at the day setting, moving it to the right (by pressing (C)) causes it to jump to the first character in the text.
 8. While the year, month, or day setting is flashing, use (D) (+) and (B) (-) to change the setting.
 - You can set a target date in the range of January 1, 1940 to December 31, 2039.
 9. After everything is the way you want, press (A) to exit the setting screen.
 - The text can show only three characters at a time, so longer text scrolls continuously from right to left. The last character is indicated by the symbol 4 after it.

Note

- Use the above procedure to edit Day Counter records, too.

To recall Day Counter records

In the Day Counter Mode, use (D) to scroll through the Day Counter records.

To delete a Day Counter record

1. In the Day Counter Mode, scroll through the records and display the one you want to delete.
2. Hold down (A) until the flashing cursor appears on the display.
3. Press (B) and (D) at the same time to delete the record.
 - The message CLR appears to indicate that the record is being deleted. After the record is deleted, the cursor appears on the display and Timekeeping Mode current date is set as the target date, ready for input.
4. Input data or press (A) to exit the setting screen.


Stopwatch

The stopwatch lets you measure elapsed time, split times, and two finishes.

- The display range of the stopwatch is 23 hours, 59 minutes, 59.99 seconds.
- The stopwatch continues to run, restarting from zero after it reaches its limit, until you stop it.
- The stopwatch measurement operation continues even if you exit the Stopwatch Mode.
- Exiting the Stopwatch Mode while a split time is frozen on the display clears the split time and returns to elapsed time measurement.
- All of the operations in this section are performed in the Stopwatch Mode, which you enter by pressing (C).

To measure times with the stopwatch

Elapsed Time



Split Time



Two Finishes



Countdown Timer

The countdown timer can be set within a range of 1 minute to 24 hours. An alarm sounds when the countdown reaches zero.

- Countdown timer functions are available in the Countdown Timer Mode, which you enter by pressing (C).

To set the countdown start time

1. In the Countdown Timer Mode, hold down (A) until the hour setting of the countdown start time starts to flash, which indicates the setting screen.
2. Press (C) to move the flashing between the hour and minute settings.
3. While a setting is flashing, use (D) (+) and (B) (-) to change it.
 - To set the starting value of the countdown time to 24 hours, set 0:00.
4. Press (A) to exit the setting screen.

To use the countdown timer

- Press (D) while in the Countdown Timer Mode to start the countdown timer.
- When the end of the countdown is reached, the alarm sounds for 10 seconds or until you stop it by pressing any button. The countdown time is automatically reset to its starting value after the alarm stops.
 - Press (D) while a countdown operation is in progress to pause it. Press (D) again to resume the countdown.
 - To completely stop a countdown operation, first pause it (by pressing (D)), and then press (A). This returns the countdown time to its starting value.
 - The countdown timer measurement operation continues even if you exit the Countdown Timer Mode.

Backlight

The backlight uses an EL (electro-luminescent) panel that causes the entire display to glow for easy reading in the dark. The watch's auto light switch automatically turns on the backlight when you angle the watch towards your face in the dark.

- The auto light switch must be turned on (indicated by the auto light switch on indicator) for it to operate.
- See "Backlight Precautions" for other important information about using the backlight.


To turn on the backlight manually

- In any mode, press (B) to illuminate the display for about one second.
- The above operation turns on the backlight regardless of the current auto light switch setting.

About the Auto Light Switch

Turning on the auto light switch causes the backlight to turn on for about one second, whenever you position your wrist as described below in any mode. Note that this watch features a "Full Auto EL Light," so the auto light switch operates only when available light is below a certain level. It does not turn on the backlight under bright light.

Moving the watch to a position that is parallel to the ground and then tilting it towards you more than 40 degrees causes the backlight to turn on.



Warning!

- Always make sure you are in a safe place whenever you are reading the display of the watch using the auto light switch. Be especially careful when running or engaged in any other activity that can result in accident or injury. Also take care that sudden illumination by the auto light switch does not surprise or distract others around you.
- When you are wearing the watch, make sure that its auto light switch is turned off before riding on a bicycle or operating a motorcycle or any other motor vehicle. Sudden and unintended operation of the auto light switch can create a distraction, which can result in a traffic accident and serious personal injury.

To turn the auto light switch on and off


In the Timekeeping Mode, hold down (B) for about two seconds to toggle the auto light switch on (☀️ displayed) or off (☀️ not displayed).

- The auto light switch on indicator (☀️) is on the display in all modes while the auto light switch is turned on.

Battery

This watch is equipped with a solar cell and a rechargeable battery (secondary battery) that is charged by the electrical power produced by the solar cell. The illustration shown below shows how you should position the watch for charging.

Example: Orient the watch so its face is pointing at a light source.




- Note that charging efficiency drops when any part of the solar cell is blocked by clothing, etc.
- The illustration shows how to position a watch with a resin band.

Important!

- Storing the watch for long periods in an area where there is no light or wearing it in such a way that it is blocked from exposure to bright light can cause rechargeable battery power to run down. Be sure that the watch is normally exposed to bright light whenever possible.
- This watch employs a solar cell that converts light into electricity, which charges a built-in rechargeable battery. Normally, the rechargeable battery should not need replacement, but after very long use over a number of years, the rechargeable battery may lose its ability to achieve a full charge. Should you notice problems with getting the rechargeable battery to a full charge, contact your dealer or CASIO distributor about having the rechargeable battery replaced.
- The rechargeable battery should be replaced with a CASIO-specified ML2016 battery only. Other rechargeable batteries can cause damage to the watch.
- All data stored in memory is deleted, and the current time and all other settings return to their initial factory defaults whenever battery power drops to Level 5 and when you have the battery replaced.
- Turn on the watch's Power Saving function and keep it in an area normally exposed to bright light when storing it for long periods. This helps to keep the rechargeable battery from going dead.

Battery Power Indicator

The battery power indicator on the display shows you the current status of the rechargeable battery's power.



- The flashing charge (C) indicator at Level 4 tells you that battery power is very low, and that exposure to bright light for charging is required as soon as possible.
 - At Level 5, all functions are disabled and settings return to their initial factory defaults. Functions are enabled once again after the rechargeable battery is charged, but you need to set the time, date, and all other settings after the battery is recharged to Level 3 from Level 5. Though the time appears on the display after the battery is charged to Level 4 (indicated by flashing charge (C) indicator), you will not be able to change the time, date, and all other settings until the battery reaches Level 3 (no charge (C) indicator).
 - Leaving the watch in direct sunlight or some other very strong light source can cause the battery power indicator to temporarily show a reading that is higher than the actual battery level. The correct battery power indicator should appear after a few minutes.
 - If you use the backlight or any of the alarm functions a number of times during a short period, the recover (R) indicator appears on the display and the following operations become disabled until battery power recovers.
- Backlight: Beeper tone**
After some time, battery power will recover and the recover (R) indicator will disappear, indicating that the above functions are enabled again.

Charging Precautions

Certain charging conditions can cause the watch to become very hot. Avoid leaving the watch in the areas described below whenever charging its rechargeable battery. Also note that allowing the watch to become very hot can cause its liquid crystal display to black out. The appearance of the LCD should become normal again when the watch returns to a lower temperature.

Warning!

Leaving the watch in bright light to charge its rechargeable battery can cause it to become quite hot. Take care when handling the watch to avoid burn injury. The watch can become particularly hot when exposed to the following conditions for long periods.

- On the dashboard of a car parked in direct sunlight
- Too close to an incandescent lamp
- Under direct sunlight

Charging Guide

After a full charge, timekeeping remains enabled for up to about six months, while the watch is used under the conditions described below.

Operating Conditions

- Watch is not exposed to light
- Display on 18 hours per day, sleep state 6 hours per day
- 1 backlight operation (1.5 seconds) per day
- 10 seconds of alarm operation per day

Charge Times

Exposing the watch to light for the periods shown below each day restores the power used by the above operating conditions.

Exposure Level (Brightness)	Approximate Exposure Time
Outdoor Sunlight (50,000 lux)	5 minutes
Sunlight Through a Window (10,000 lux)	24 minutes
Daylight Through a Window on a Cloudy Day (5,000 lux)	48 minutes
Indoor Fluorescent Lighting (500 lux)	8 hours

- Stable operation is promoted by frequent charging.

Recovery Times

The table below shows the amount exposure that is required to take the battery from one level to the next.

Exposure Level (Brightness)	Approximate Exposure Time				
	Level 5	Level 4	Level 3	Level 2	Level 1
Outdoor Sunlight (50,000 lux)	33 hours	3 hours	16 hours	2 hours	2 hours
Sunlight Through a Window (10,000 lux)	166 hours	16 hours	80 hours	12 hours	12 hours
Daylight Through a Window on a Cloudy Day (5,000 lux)	---	33 hours	162 hours	25 hours	25 hours


- The above exposure time values are all for reference only. Actual required exposure times depend on lighting conditions.

Reference

This section contains more detailed and technical information about watch operation. It also contains important precautions and notes about the various features and functions of this watch.

Power Saving Function

Power saving on indicator



When turned on, the Power Saving function automatically puts the watch into a sleep state whenever it is left in an area where it is dark for about one hour in the Timekeeping Mode or Auto Display screen. The sleep state is indicated by a blank screen with Power Saving on (S) indicator flashing on it. In the sleep state, all functions are enabled, except for the display.

- Wearing watch inside the sleeve of clothing can cause it to enter the sleep state.

- The watch will not enter the sleep state between 6:00 AM and 9:59 PM. If the watch is already in the sleep state when 6:00 AM arrives, however, it will remain in the sleep state.

To recover from the sleep state

Perform any one of the following operations.

- Move the watch to a well-lit area. It can take up to five seconds for the display to turn on.
- Press any button.
- Angle the watch towards your face for reading.

To turn Power Saving on and off



In the Timekeeping Mode, hold down (D) for about two seconds to toggle Power Saving on (S indicator displayed) and off (S indicator not displayed).

- Note that pressing (D) also toggles between 12-hour timekeeping and 24-hour timekeeping.

Auto Display



Auto Display continually changes the contents of the digital display.

To turn off Auto Display

Press any button (except for (B)) to turn off Auto Display. This returns to the Timekeeping Mode.

To turn on Auto Display

Hold down (C) for about three seconds until the watch beeps.

- Note that Auto Display cannot be performed while a setting screen is on the display.

Auto return features

- After you perform any button operation (except for the backlight button) in any mode, pressing (C) returns directly to the Timekeeping Mode.
- If you leave the watch in the Data Bank, Alarm, and Day Counter Mode for two or three minutes without performing any operation, it automatically changes to the Timekeeping Mode.
- If you leave a screen with flashing digits or a cursor on the display for two or three minutes without performing any operation, the watch automatically saves any settings you have made up to that point and exits the setting screen.

Data and Setting Scrolling

The (B), (C), and (D) buttons are used in various modes and setting screens to scroll through data on the display. In most cases, holding down these buttons during a scroll operation scrolls through the data at high speed.

Initial Screens

When you enter the Data Bank, Alarm, or Day Counter Mode, the data you were viewing when you last exited the mode appears first.

Timekeeping

- Resetting the seconds to 00 while the current count is in the range of 30 to 59 causes the minutes to be increased by 1. In the range of 00 to 29, the seconds are reset to 00 without changing the minutes.
- The year can be set in the range of 2000 to 2039.
- The watch's built-in full automatic calendar automatically makes allowances for different month lengths and leap years. Once you set the date, there should be no reason to change it except after you have the watch's battery replaced or when battery power drops to Level 5.

