



RONDA normtech

– 788/708

You have decided to buy a watch, which was assembled by a watchmaker using a Ronda movement. Please note that no watches are produced or distributed under the Ronda brand.

In case of repairs, guarantee claims and questions concerning the functioning of a watch, purchasers and consumers should contact their retailer or the watch manufacturer, for which the relevant information can be found in the sales or guarantee documentation provided with the watch.

Cal. 788 / 708

- Pos. I Position of rest** (watch running)
- Pos. II Quick-change correction for date**
Blocking time for the quick-change day correction is from approx. 9.30 pm and midnight.
- Pull the crown out to position II (watch still running).
 - Turn the crown until the current date appears.
 - Push the crown back into position I.
- Pos. III Setting the time**
- Pull the crown out to position III (watch stopped).
 - Turn the crown, until the current time is displayed (remember the 24-hour cycle).
 - Push the crown back into position I.

Cal. 788 / 708

Setting the moonphase display

There is no quick-change correction available setting the moonphase.

- Pull the crown out to position III (watch stopped).
- Turn the hands forward by turning the crown, until the current moonphase display appears.
- Push the crown back into position II and set the current date using the quick change correction.
- Push the crown back into position I.

Full moon dates

	2019	2020	2021	2022	2023	2024	2025	2026
JAN	21	10	28	18	07	25	13	3
FEB	19	09	27	16	05	24	12	1
MAR	21	09	28	18	07	25	14	3
APR	19	08	27	16	06	24	13	2
MAY	18	07	26	16	05	23	12	1/31
JUN	17	05	24	14	04	22	11	30
JUL	16	05	24	13	03	21	10	29
AUG	15	03	22	12	1/31	19	09	28
SEP	14	02	21	10	29	18	07	26
OCT	13	01/31	20	09	28	17	07	26
NOV	12	30	19	08	27	15	05	24
DEC	12	30	19	08	27	15	05	24

Cal. 788:

Battery type: 362/SR721SW

Cal. 708:

Battery type: 371/SR920SW

Precision: +20/-10 seconds per month